

Lipstick - "Dreamberry"

Color Cosmetics

Ref: CC/0005/EU

Product Name	INCI Name	%W/W	Supplier
A			
		100.00	
Ewacera 34	Carnauba Wax	4.50	www.wagnerlanolin.de
Ewacera 12	Bees Wax	3.50	www.wagnerlanolin.de
Ewacera 42	Candelilla Wax	4.00	www.wagnerlanolin.de
Parcera MW	Microcrystalline Wax	7.20	www.paramelt.com
Walrath synthetic	Cetyl Palmitate	2.00	www.kahlwax.de
Softisan 100	Hydrogenated Coco-Glycerides	5.00	www.sasolwax.com
Penreco Blond	Petrolatum	5.80	www.penreco.com
Luvitol EHO	Cetearyl Octanoate	10.70	www.basf.com
D,L-Alpha-Tocopherolacetat	Tocopheryl Acetate	0.50	www.dsm.com
Castor Oil	Castor Oil	39.60	www.riedelhehaen.com
B			
Visionaire® Bright Red 7	Aluminum Powder (and) Silica (and) Red 7	6.00	www.eckart.net
Prestige® Bronze	Mica (and) Iron Oxides	6.00	www.eckart.net
Prestige® Silk Silver	Mica (and) Titanium Dioxide	5.00	www.eckart.net
Rokonsal SSH-1	Methylparaben, Propylparaben	0.20	www.biochema.com

Procedure

1. Heat phase A to 85°C
2. Add phase B to phase A and mix
3. Pour into a lipstick mould at 75°C

Stability

Stable for at least 6 months at RT and 40°C.

Remark: Aluminum pigments are not allowed for lip application in the USA.

Customer Support

ECKART GmbH & Co. KG
info.eckart@altana.com

ECKART Cosmetic Colours LLC
info.eckart.cosmetics@altana.com

ECKART Asia Limited
info.eckart.asia@altana.com

This information and our technical advice - whether verbal, in writing or by way of trials - are given in good faith but without warranty, and this also applies where proprietary rights of third parties are involved. Our advice does not release you from the obligation to verify the information currently provided - especially that contained in our safety data and technical information sheets - and to test our products as to their suitability for the intended processes and uses. The application, use and processing of our products and the products manufactured by you on the basis of our technical advice are beyond our control and, therefore, entirely your own responsibility.