

Pressed Eye Shadow - 2008 Trend Color - "Lustrous Pistachio"

Color Cosmetics

Ref: CC/0318/EU

Product Name	INCI Name	%W/W	Supplier
A			
		100.00	
Silk Mica	Mica	17.00	www.vwr.com
Softouch CCS 102	Boron Nitride	2.50	www.advceramicscos.com
Talc Powder	Talc	23.50	www.riedeldehaen.com
Kemilub EZ-V	Zinc Stearate	7.00	www.undesa.com
Prestige® Emerald	Mica (and) Titanium Dioxide (and) Iron Oxides (and) Ferric Ferrocyanide (and) Tin Oxide	25.00	www.eckart.net
Visionaire® Bright Champagne	Aluminum Powder (and) Aluminum Hydroxide	15.00	www.eckart.net
B			
Dow Corning® 200 Fluid 5 cst	Dimethicone	5.00	www.dowcorning.com
Dow Corning® 9040 Elastomer	Cyclomethicone (and) Dimethicone Crosspolymer	5.00	www.dowcorning.com

Procedure

1. Mix phase A
2. Add phase B and stir until homogenous
3. Press eye shadow at 150 bar for 30 s

Stability

Stable for at least 3 months at RT and 40°C.

Customer Support

ECKART GmbH & Co. KG
info.eckart@altana.com

ECKART Cosmetic Colours LLC
info.eckart.cosmetics@altana.com

ECKART Asia Limited
info.eckart.asia@altana.com

This information and our technical advice - whether verbal, in writing or by way of trials - are given in good faith but without warranty, and this also applies where proprietary rights of third parties are involved. Our advice does not release you from the obligation to verify the information currently provided - especially that contained in our safety data and technical information sheets - and to test our products as to their suitability for the intended processes and uses. The application, use and processing of our products and the products manufactured by you on the basis of our technical advice are beyond our control and, therefore, entirely your own responsibility.