

Lip Gloss “MIRAGE Bright Luminous Red – 2.5%”

Color Cosmetics

Ref: CC/3254/EU

Product Name	INCI Name	%W/W	Supplier
A		100.00	
Versagel ME 750	Hydrogenated Polyisobutene (and) Ethylene/Propylene/Styrene Copolymer (and) Butylene/Ethylene/Styrene Copolymer	79.20	www.penreco.com
Labrafac CC	Caprylic/Capric Triglyceride	6.00	www.gattefosse.com
Silshine 151 Fluid	Phenylpropyldimethylsiloxysilicate	6.00	www.momentive.com
Silsoft 034	Caprylyl Methicone	6.00	www.momentive.com
B			
MIRAGE Bright Luminous Red	Calcium Sodium Borosilicate (and) Iron Oxides (and) Tin Oxide	2.50	www.eckart.net
Chocolate Nut	Flavor	0.30	

Procedure:

1. Combine phase A and heat up to 70°C
2. Add phase B and mix with moderate shear until homogeneous

⇒ MIRAGE Bright Luminous Red gives the formulation a pure red colored brilliant effect



Stability:

Stable for at least 6 months at RT and 40°C.
Stable for at least 1 month at 50°C.

Customer Support

ECKART GmbH
info.eckart@altana.com

ECKART America Corporation
info.eckart.cosmetics@altana.com

ECKART Asia Limited
info.eckart.asia@altana.com

This document does not constitute a legally binding obligation of Eckart. While the information contained herein and our technical advice – whether verbal, in writing or by way of trials – are given in good faith, it is provided for your guidance only. We recommend testing our products as to their suitability for your envisaged purpose prior to use. Furthermore, you are responsible for observing all laws and regulations relevant to any products mentioned herein and the products' application. No warranties of any kind, either express or implied, including warranties of merchantability or fitness for a particular purpose, are made regarding any products mentioned herein and data or information set forth, or that such products, data or information may be used without infringing intellectual property rights of third parties.

Date: 30.08.2021
Revision : 30.08.2021