



## Color Me Awake Fluid – “Eye`m Fresh!”

Color Cosmetics

Ref: CC/3777/EU

Product Name	INCI Name	%W/W	Supplier
<b>A</b>			
		100.00	
Emulium Illustro	Polyglyceryl-6 Polyhydroxystearate (and) Polyglyceryl-6 Polyricinoleate (and) Polyglycerin-6	4.50	www.gattefosse.com
Lexfeel Natural	Heptyl Undecylenate	5.00	www.inolex.com
Eyeglorius	Octyldodecyl Myristate (and) Hippophae Rhamnoides Extract	2.00	www.gattefosse.com
Cetiol CC	Dicaprylyl Carbonate	5.00	www.personal-care.basf.com
Lipocire A SG Pellets	C10-18 Triglycerides	2.00	www.gattefosse.com
TIXOGEL-CCT	Caprylic/Capric Triglyceride (and) Stearalkonium Bentonite (and) Propylene Carbonate	6.00	www.byk.com
<b>B</b>			
Water	Aqua	57.40	
Sodium Chloride	Sodium Chloride	1.00	
Magnesiumsulfat-Hydrat	Magnesium Sulphate	2.00	
<b>C</b>			
Goldmann Ti White R AO	CI 77891 / persea gratissima (avocado) oil / hydrogenated vegetable oil / tocopherol	2.50	www.gold-mann.de
Goldmann Fe Yellow AO	CI 77891 / persea gratissima (avocado) / hydrogenated vegetable oil / tocopherol	0.60	www.gold-mann.de
Goldmann Fe Red AO	CI 77491 / persea gratissima (avocado) oil / hydrogenated vegetable oil / tocopherol	0.20	www.gold-mann.de
Goldmann Fe Black AO	CI 77499 / persea gratissima (avocado) oil / hydrogenated vegetable oil / tocopherol	0.05	www.gold-mann.de
<b>D</b>			
<b>SYNCRYSTAL Orange</b>	<b>Synthetic Fluorphlogopite (and) Titanium Dioxide (and) Tin Oxide</b>	<b>10.00</b>	<b>www.eckart.net</b>
<b>SYNAFIL S115</b>	<b>Synthetic Fluorphlogopite</b>	<b>3.65</b>	<b>www.eckart.net</b>
Gatuline Link n Lift	Fructose (and) Glycerin (and) Water (and) Aesculus Hippocastanum (Horse Chestnut) Extract	2.00	www.gattefosse.com
White Jasmine Bliss	Fragrance	0.10	www.bell-europe.com
Euxyl PE 9010	Phenoxyethanol, Ethylhexylglycerin	1.00	www.ashland.com

### Procedure:

1. Weigh in phase A and B separately
2. Add phase C to phase A and homogenize until homogeneous
3. Heat phase AC and B to 40°C
4. Add slowly B to AC and homogenize
5. Add phase D step by step at medium shear
6. Adjust pH to 6.5 if necessary
7. Fill into an appropriate container

- ⇒ In this formulation, **SYNCRYSTAL Orange** can effectively brighten and neutralize dark, blue-toned under-eye circles.
- ⇒ **SYNCRYSTAL S115** boosts spreadability and skin comfort.



### Stability:

Stable for at least 1 month at 50°C.

### Customer Support

ECKART GmbH  
info.eckart@altana.com

ECKART Cosmetic Colors LLC  
info.eckart.cosmetics@altana.com

ECKART Asia Limited  
info.eckart.asia@altana.com

This document does not constitute a legally binding obligation of Eckart. While the information contained herein and our technical advice – whether verbal, in writing or by way of trials – are given in good faith, it is provided for your guidance only. We recommend testing our products as to their suitability for your envisaged purpose prior to use. Furthermore, you are responsible for observing all laws and regulations relevant to any products mentioned herein and the products' application. No warranties of any kind, either express or implied, including warranties of merchantability or fitness for a particular purpose, are made regarding any products mentioned herein and data or information set forth, or that such products, data or information may be used without infringing intellectual property rights of third parties.

Date: 25.03.2026  
Revision : 25.03.2026