



Let it Glow!

Glammy Highlighter Stick - "Glow'rious Wonderland"

Color Cosmetics

Product Name	INCI Name	%W/W 100.00	Supplier
Miglyol PPG 810	Propylene Glycol Dicaprylate/Dicaprate	27.40	www.ioioleo.de
Ceraphyl 847	Octyldodecyl Stearoyl Stearate	11.00	www.ashland.com
Acticire	Jojoba Esters and Acacia Decurrens Flower Wax and Helianthus Annuus (Sunflower) Seed Wax and Polyglyceryl-3	5.00	www.gattefosse.com
Lipocire A Pellets	C10-18 Triglycerides	5.00	www.gattefosse.com
Lexgard O	Caprylyl Glycol	1.00	www.inolex.com
Kahlwax 6700	Copernicia Cerifera Cera (and) Polyethylene (and) C30-50 Alcohols (and) Montan Acid Wax (and) Shorea Robusta Resin (and) Hydrogenated Styrene/Methylstyrene/Indene Copolymer	6.50	www.kahlwax.com
TIXOGEL-VSP	Cyclomethicone (and) Quaternium-90 Bentonite (and) Propylene Carbonate	15.00	www.eckart.net
В			
Granpowder USQ	Polymethylsilsesquioxane (and) HDI/Trimethylol Hexyllactone Crosspolymer	6.50	www.grantinc.com
Agenaflo OS 9051	Aluminum Starch Octenylsuccinate	6.00	www.agrana.com
SYNAFIL S1050	Synthetic Fluorphlogopite	7.00	www.eckart.net
MIRAGE Champagne	Calcium Sodium Borosilicate (and) Iron Oxides	0.50	www.eckart.net
MIRAGE Sparkling Silver	Calcium Sodium Borosilicate (and) Titanium Dioxide (and) Tin Oxide	2.00	www.eckart.net
MIRAGE Glamour Gold	Calcium Sodium Borosilicate (and) Titanium Dioxide (and) Tin Oxide	3.00	www.eckart.net
MIRAGE Glamour Red	Calcium Sodium Borosilicate (and) Titanium Dioxide (and) Tin Oxide	4.00	www.eckart.net
Angieberry	Fragrance	0.10	www.drom.com

Procedure:

- 1. Melt phase A by heating to 80-85°C
- 2. Add the ingredients of phase B
- 3. Stir until uniform and pour into stick mold
- 4. Cool down to RT



Stable for at least 6 months at RT and 40°C. Stable for at least 1 month at 50°C.



- ⇒ MIRAGE Champagne provides that beautiful nude tone
- ⇒ MIRAGE Sparkling Silver, MIRAGE Glamour Gold and MIRAGE Glamour Red provides a sublime shine and a gorgeous glow to the skin for the ultimate highlighted effect
- ⇒ SYNAFIL S1050 creates a velvet-like skin feel and improves skin adhesion
- ⇒ TIXOGEL-VSP avoids settling of the pigments during the mold and improves the spreadability of the wax formulation on the skin

Customer Support

ECKART GmbH info.eckart@altana.com

ECKART America Corporation info.eckart.cosmetics@altana.com

ECKART Asia Limited info.eckart.asia@altana.com

This document does not constitute a legally binding obligation of Eckart. While the information contained herein and our technical advice – whether verbal, in writing or by way of trials – are given in good faith, it is provided for your guidance only. We recommend testing our products as to their suitability for your envisaged purpose prior to use. Furthermore, you are responsible for observing all laws and regulations relevant to any products mentioned herein and the products' application. No warranties of any kind, either express or implied, including warranties of merchantability or fitness for a particular purpose, are made regarding any products mentioned herein and data or information set forth, or that such products, data or information may be used without infringing intellectual property rights of third parties.

Date: 13.11.2019 Revision: 13.11.2019

